

Succorfish UW Modem

Succorfish Delphis V3 underwater acoustic modem based on Newcastle University's [Nanomodem](#).

Link to the product: <https://succorfish.com/products/delphis/>

Updated drivers:

nm3firmwareupdatefiles-20230531.zip

Technical specifications:

delphis-data-sheet_v9_3.2.pdf

User guide:


succorfish_delphis_user_guide_v4.pdf

Delphi cable pinout:

delphis_cable_pin_out.pdf


smarc_acomms

Underwater communications for SAM and LoLo, compatible with NanoModem3 acoustic modem : https://github.com/matthew-william-lock/smarc_acomms



LABUST Nanomodem Driver

LABUST has written a low-level ROS driver for the Delphis V3. In other words, the driver allows us to use ROS to trigger the same functions as defined in the **user guide**. The driver does not allow for the transmission of arbitrary ROS messages. Shown below is an overview of the driver structure for RX and TX.



Launching ROS Node

```
roslaunch labust_nanomodem nanomodem.xml driver_port:=/dev/ttyUSB0
```

Q&A

Below are some questions we have asked succorfish.

Potting of OEM Module

Q- What material should be used for potting?

A- Polyurethane Potting Compound. Product suggestion:

<https://www.acoustics.co.uk/product/aptflex-f21/>

Q- How thick should the potting be outside the module?

A- 1-3mm would be the recommended thickness.


Note: Ensure to heat your potting solution to 45 degrees for an hour to give a nice smooth (no bubbles) finish.

Other questions

Q- Is it ok to run the pcb without a transducer plugged in?
A- Succorfish cannot guarantee nothing will happen, but they have done this multiple times with no issue.

PCB Pinout

See pinout on the PCB below.



J3: Transducer


J2: Main Connect

J2 – Main connector		J3 - Transducer	
1	Logic level UART TXD (2.5V)	1	Inner
2	Hydrophone output (analog)	2	Outer
3	Logic level UART RXD (2.5V)		
4	ADC input (ch 4a)		
5	RxS flag (2.5V logic)		
6	ADC input (ch 3)		
7	Vbat (+ve supply) *		
8	Vbat (+ve supply) *		
9	GND (0V) *		
10	GND (0V) *		
11	Serial TXD (RS232 output)		
12	DAC output		
13	Serial RXD (RS232 input)		
14	SPI MISO		

USB Adapter

The [RS232 converter](#) has the following pinout.

To get power on V_out, R3 needs to be bridged.



Serial Commands


These commands (not complete list) were extracted from the [NM3 driver repo](#) and include things like noise magnitude, Fourier spectrum and multipath measurements **not** available in the user guide.

Command	Serial Code	Purpose	Typical Usage / Parameters
Query Status	\$?	Reads the modem's status including address, battery voltage, version.	`"\$?"` → response with address, voltage, version strings.
Set Address	\$A	Change the modem's network address.	`"\$Axxx"` - set to numeric address.
Broadcast Data	\$B	Send a broadcast message.	`"\$Bnnddd"` - no ACK expected.
Channel Impulse Response	\$C	Request impulse response from a remote node (Binary). This can be used to estimate multipath effects and phases.	`"\$CMxxx"` (magnitude) or `"CCxxx"` (complex).
Noise Measurement	\$N	Measure ambient noise.	`"\$N"` → returns RPM RMS , Peak-to-Peak , mean magnitude e.g. #NR000132P001089M000106
Ping	\$P	Acoustic ping to remote.	`"\$Pxxx"` → returns time of arrival.
Spectrum Measurement	\$S	Measure local noise spectrum.	`"\$S"` → returns number of FFT bins(ASCII) and values(Binary, won't be read with screen). Bin frequencies of bin k is likely $\text{freq}[k] = k \times 160000 / 512$
Unicast with Ack	\$M	Send a unicast message and expect ACK.	`"\$Mxxnnddd"` (+ optional timeout/time tag).
Unicast (no ACK)	\$U	Send a unicast message only.	`"\$Uxxnnddd"`.
System Timer Enable	\$XT *(Enable/Disable variants)*	Manage system timestamp counter for timed tx/rx.	`"\$XTEN"` to enable, `"XTDI"` to disable, `"XTCL"` to clear, etc.
Get Timer Status	\$XT?	Read current timer status and count.	`"\$XT?"`.
Delayed Broadcast	\$B with timestamp	Same as ` <b>\$B</b> ` but includes a *time tag* for future transmit.	`"\$Bddd<timestamp_count>(NOT ASCII)"`.
Delayed Unicast	\$U with timestamp	As above for unicast.	`"\$Uxxddd,<timestamp_count>(NOT ASCII)"`.


Delayed Unicast Ack	\$M with timestamp	As above for unicast with ACK.	`"\$Mxxxxdd<timeout>,<timestamp_count>(NOT ASCII)"`.
---------------------	---------------------------	--------------------------------	--

Diagnostics

Here's what a properly parsed output of the **\$S** command can look like, a Noise Spectral Density where we can se the gain window of the modem between 20-40 kHz.:



And here's the output of the **\$CM** command, a simplified Channel Impulse Response where the 1m peak correponds to the direct line and a reflected path arrives with a 2m longer path (5ms in air):



Using a scope we can check the time response of the modem instructed by a microcontroller. Here are some delay values sending a command to the NM3 over serial (9600) from the Teensy 4.1:

From → To	Delay
teensy.write → Transmission start	17 ms
Ping End, modem 1 → Ping answer, modem 2	8 ms
Ping Start, modem 1 → Flag raised, modem 2	30 ms

From:

<https://mrl.wiki/> - **MRL wiki 1**

Permanent link:

<https://mrl.wiki/sensors:succorfish>

Last update: **2026/01/16 11:01**

